




—  
—  
—

--	--	--	--

















Condition for is IFP pulse: Pulse Width 0.1ms and duty 1/10.

--	--	--	--



LIGHT ELECTRONICS CO., LTD.








--	--	--	--



0.5 0.3 0.1 0.2 0.4 0.6

## Label Explanation

<b>LIGHT</b> Light Electronics CO., LTD.		LOT NO. : ON LOT
MODEL NAME: _____		
QUANTITY: _____		
BIN: _____		
PACKING DATE: _____		
REMARKS: _____		




## Reel Dimensions

--	--	--	--



## Suggest IR Reflow Condition For Lead Free



1. Reflow soldering should not be done more than two times.
2. When soldering, do not put stress on the LEDs during heating.

### Soldering iron

1. When hand soldering, the temperature of the iron must less than 300 °C for 3 seconds.
2. The hand solder should be done only once.

### Repairing

Repair should not be done after the LEDs have been soldered. When repairing is unavoidable, a double-head soldering iron should be used (as below figure). It should be confirmed beforehand whether the characteristics of LEDs will or will not be damaged by repairing.

